

1.1 Controlling the Module

Communication with the module is by standard VME bus protocols. All registers and memory locations are defined to be 4-byte entities. The VME slave module has three distinct address ranges.

A24 – The base address of this range is set by a 12-element DIP switch on the board. It occupies 4 Kbytes of VME address space, organized in 1 K 32-bit words. Relative to the base address, this space is divided as follows:

000-0FF – Register space to control and monitor the module (64 long words)

100-1FF – ADC FPGA processing registers (64 long words)

200-2FF – HITSUM FPGA processing registers (64 long words)

300-FFF – Reserved (832 long words)

In addition to registers that are directly mapped to a VME address (Primary Address), the module supports Secondary Addressing in the A24 address space. These registers are accessed through an address mapping register (Secondary Address Register). Each secondary address is associated with a primary address. A Primary Address may have up to 64 K secondary addresses associated with it. A VME cycle loads the mapping register with data which is the internal (secondary) address of the target register. A VME cycle with the associated primary address accesses (read/write) the chosen internal register. Important registers are assigned primary addresses, allowing them to be directly accessible in a single VME cycle. Setup tables are assigned secondary addresses. This allows for a large internal address space, while maintaining a small VME footprint.

A32 - The base address of this range is programmed into register ADR32. It occupies 8 Mbytes of VME address space, organized in 2 M 32-bit words. A read of any address in this range will yield the next FADC data word from the module. Even though the module is logically a FIFO, the expanded address range allows the VME master to increment the address during block transfers. This address range can participate in single cycle, 32-bit block, and 64-bit block reads. The only valid write to this address range is the data value 0x80000000 which re-enables the module to generate interrupts (after one has occurred). The address range must be enabled by setting ADR32[0] = 1.

A32 - The lower and upper limits of this address range are programmed into register ADR_MB. This common address range for a set of FADC modules in the crate is used to implement the Multiblock protocol. By means of token passing FADC data may be read

out from multiple FADC modules using a single logical block read. The board possessing the token will respond to a read cycle in this address range with the next FADC data word from that module. The token is passed along a private daisy chain line to the next module when it has transferred all data from a programmed number of events (register BLOCK SIZE). The address range must be enabled by setting ADR_MB[0] = 1.

1.3 Module Registers

VERSION – board/firmware revision (0x0)

[7...0] – (R) – firmware revision

[15...8] – (R) – board revision

[31...16] – (R) – board type (“FADC”)

CSR – Control/Status (0x4)

0 – (R) – Event Accepted

1 – (R) – Block of Events Accepted

2 – (R) – Block of Events ready for readout

3 – (R) – BERR Status (1 = BERR asserted)

4 – (R) – Token Status (1 = module has token)

5 – (R) – PLL 1 Locked

6 – (R) – PLL 2 Locked

7 – (R) – PLL 3 Locked

8 – (R) – PLL 1 Loss of Lock Occurred

9 – (R) – PLL 2 Loss of Lock Occurred

10 – (R) – PLL 3 Loss of Lock Occurred

11 – (R) – Data FIFO 1 (channels 1 – 8) Empty Flag Asserted

- 12 – (R) – Data FIFO 1 (channels 1 – 8) Almost Empty Flag Asserted
- 13 – (R) – Data FIFO 1 (channels 1 – 8) Half Full Flag Asserted
- 14 – (R) – Data FIFO 1 (channels 1 – 8) Almost Full Flag Asserted
- 15 – (R) – Data FIFO 1 (channels 1 – 8) Full Flag Asserted
- 16 – (R) – Data FIFO 2 (channels 9 – 16) Empty Flag Asserted
- 17 – (R) – Data FIFO 2 (channels 9 – 16) Almost Empty Flag Asserted
- 18 – (R) – Data FIFO 2 (channels 9 – 16) Half Full Flag Asserted
- 19 – (R) – Data FIFO 2 (channels 9 – 16) Almost Full Flag Asserted
- 20 – (R) – Data FIFO 2 (channels 9 – 16) Full Flag Asserted
- 21 – (R) – HITSUM FIFO Empty Flag Asserted
- 22 – (R) – HITSUM FIFO Almost Empty Flag Asserted
- 23 – (R) – HITSUM FIFO Half Full Flag Asserted
- 24 – (R) – HITSUM FIFO Almost Full Flag Asserted
- 25 – (R) – HITSUM FIFO Full Flag Asserted
- 26 – (R) – Local Bus Time Out – target AK or DK timed out (5 us);
- 27 – (R/W) – Local Bus Error – target protocol violation;
(write ‘1’ clears latched bits 26, 27)
- 28 – (W) – Pulse Soft Sync Reset (if CTRL[11] = 1)
- 29 – (W) – Pulse Soft Trigger (if CTRL[7] = 1)
- 30 – (W) – Pulse Soft Reset
- 31 – (W) – Pulse Hard Reset

CTRL1 – Control 1 (0x8)

- [2...0] – (R/W) – Sampling Clock Source Select
0 = P2 connector (also 2,4,6)

1 = Front Panel connector (also 3)
5 = P0 connector
7 = Internal Clock

3 – (R/W) – Enable Internal Clock

[6...4] – (R/W) – Trigger Source Select

0 = Front Panel Connector
1 = Front Panel Connector (synchronized internally)
2 = P0 Connector
3 = P0 Connector (synchronized internally)
4 = P2 Connector
5 = P2 Connector (synchronized internally)
6 = VME (software generated)
7 = Module Internal Logic (synchronized internally)

7 – (R/W) – Enable Soft Trigger

[10...8] – (R/W) – Sync Reset Source Select

0 = Front Panel Connector
1 = Front Panel Connector (synchronized internally)
2 = P0 Connector
3 = P0 Connector (synchronized internally)
4 = P2 Connector
5 = P2 Connector (synchronized internally)
6 = VME (software generated)
7 = no source

11 – (R/W) – Enable Soft Sync Reset

12 – (R/W) – Select Live Internal Trigger to Output

13 – (R/W) – Enable Front Panel Trigger Output

14 – (R/W) – Enable P0 Trigger Output

15 – (R/W) – Enable P2 Trigger Output

16 – (R/W) – Enable Readout of ADC channels 1 – 8

17 – (R/W) – Enable Readout of ADC channels 9 – 16

18 – (R/W) – Enable Event Level Interrupt

19 – (R/W) – Enable Error Interrupt

- 20 – (R/W) – Enable BERR response
- 21 – (R/W) – Enable Multiblock protocol
- 22 – (R/W) – FIRST board in Multiblock system
- 23 – (R/W) – LAST board in Multiblock system
- 24 – (R/W) – Bypass External RAM
- 25 – (R/W) – Enable Debug Mode
- 26 – 27 – (not used – read as 1)
- 28 – (R/W) – Multiblock Token passed on P0
- 29 – (R/W) – Multiblock Token passed on P2
- 30 – 31 – (not used – read as 1)

CTRL2 – Control 2 (0xC)

- 0 – (R/W) – GO (allow data transfer from external FIFOs to input FIFOs)
- 1 – (R/W) – Enable Trigger to Module (source = CTRL1[6...4])
- 2 – (R/W) – Enable Sync Reset to Module (source = CTRL1[10...8])
- 3 – (R/W) – Enable Internal Trigger Logic
- 4 – (R/W) – Enable Streaming mode (NO event build)
- 5 – (R/W) – Select data for readout (0 = channels 1 – 8, 1 = channels 9 – 16)
(streaming mode only)

Bits 16 – 31 are functional only in Debug Mode (CTRL1[25] = 1)

- 16 – (R/W) – Transfer data: input FIFO → build FIFO
- 17 – (R/W) – Transfer data: build FIFO → output FIFO
- 30 – (R/W) – Disable external FIFO output (channels 1 – 8)
- 31 – (R/W) – Disable external FIFO output (channels 9 – 16)

BLOCK SIZE (0x10)

[15...0] - (R/W) – number of events in a BLOCK.
Stored Event Count \geq BLOCK SIZE \rightarrow CSR[3] = 1.

[31...16] – (not used)

INTERRUPT (0x14)

[7...0] – (R/W) – Interrupt ID (vector)

[10...8] – (R/W) – Interrupt Level [2..0]. Valid values = 1,...,7.

11 - 15 – (not used)

[20...16] – (R) – Geographic Address (slot number) in VME64x chassis.

21 – 22 – (not used)

23 – (R) – Parity Error in Geographic Address.

24 – 31 – (not used)

ADR32 – Address for data access (0x18)

0 – (R/W) – Enable 32-bit address decoding

1 – 6 – (not used – read as 0)

[15...7] – (R/W) – Base Address for 32-bit addressing mode (8 Mbyte total)

ADR_MB – Multiblock Address for data access (0x1C)

0 – (R/W) – Enable Multiblock address decoding

1 – 6 – (not used – read as 0)

[15...7] – (R/W) – Lower Limit address (ADR_MIN) for Multiblock access

16 – 22 – (not used – read as 0)

[31...23] – (R/W) – Upper Limit address (ADR_MAX) for Multiblock access

The board that has the TOKEN will respond with data when the VME address satisfies the following condition:

$$\text{ADR_MIN} \leq \text{Address} < \text{ADR_MAX}.$$

SEC_ADR – Secondary Address (0x20)

[15...0] – (R/W) – Secondary Address for 24-bit addressing mode

16 – (R/W) – Enable auto-increment mode (secondary address increments by 1 after each access of the associated primary address)

DELAY – Trigger/Sync Reset Delay (0x24)

[21...16] – (R/W) – Sync reset delay

[5...0] – (R/W) – Trigger delay

INTERNAL TRIGGER CONTROL (0x28)

[23...16] – (R/W) – trigger width (4 ns per count)

[7...0] – (R/W) – trigger hold off delay (4 ns per count)

RESET CONTROL (0x2C)

0 – (W) – Hard reset – Control FPGA

1 – (W) – Hard reset – ADC processing FPGA 1 (channels 1 – 8)

2 – (W) – Hard reset – ADC processing FPGA 2 (channels 9 – 16)

3 – (W) – Hard reset – HITSUM FPGA

4 – (W) – Soft reset – Control FPGA

5 – (W) – Soft reset – ADC processing FPGA 1 (channels 1 – 8)

6 – (W) – Soft reset – ADC processing FPGA 2 (channels 9 – 16)

7 – (W) – Soft reset – HITSUM FPGA

- 8 – (W) – Reset – ADC data FIFO 1 (channels 1 - 8)
- 9 – (W) – Reset – ADC data FIFO 2 (channels 9 - 16)
- 10 – (W) – Reset – HITSUM FIFO
- 11 – (W) – Reset – DAC (all channels)
- 12 – (W) – Reset – EXTERNAL RAM Read & Write Address Pointers
- 13 – 31 – (not used)

TRIGGER COUNT (0x30)

- [31...0] – (R) – total trigger count
- 31 – (W) – reset count

EVENT COUNT (0x34)

- [23...0] – (R) – number of events on board (non-zero → CSR[0] = 1).
- [31...24] – (not used)

BLOCK COUNT – (0x38)

- [31...20] – not used
- [19...0] – (R) - number of event BLOCKS on board (non-zero → CSR[2] = 1).

BLOCK FIFO COUNT – (0x3C)

- [31...6] – not used
- [5...0] – (R) - number of entries in BLOCK WORD COUNT FIFO

BLOCK WORD COUNT FIFO – (64 deep FIFO) (0x40)

- [31...25] – not used (read as ‘0’)

24 – (R) – count not valid (word count FIFO empty)

[23...20] – not used (read as ‘0’)

[19...0] – (R) - number of words in next event BLOCK

INTERNAL TRIGGER COUNT (0x44)

[31...0] – (R) – internal live trigger count

31 – (W) – reset count

EXTERNAL RAM WORD COUNT (0x48)

[31...22] – not used (read as ‘0’)

21 – (R) – RAM empty

20 – (R) – RAM full (1,048,576 eight byte words)

[19...0] – (R) – data word count (eight byte words)

DATA FLOW STATUS (0x4C)

DAC 1_2 – DAC channels 1,2 (0x50)

31 – (W) – load DAC channels 1 – 8

[30...24] – (not used – read as 0)

[23...16] – (R/W) – DAC value channel 1

15 – (W) – load DAC channels 1 – 8

[14...8] – (not used – read as 0)

[7...0] – (R/W) – DAC value channel 2

DAC 3_4 – DAC channels 3,4 (0x54)

31 – (W) – load DAC channels 1 – 8
[30...24] – (not used – read as 0)
[23...16] – (R/W) – DAC value channel 3
15 – (W) – load DAC channels 1 – 8
[14...8] – (not used – read as 0)
[7...0] – (R/W) – DAC value channel 4

DAC 5_6 – DAC channels 5,6 (0x58)

31 – (W) – load DAC channels 1 – 8
[30...24] – (not used – read as 0)
[23...16] – (R/W) – DAC value channel 5
15 – (W) – load DAC channels 1 – 8
[14...8] – (not used – read as 0)
[7...0] – (R/W) – DAC value channel 6

DAC 7_8 – DAC channels 7,8 (0x5C)

31 – (W) – load DAC channels 1 – 8
[30...24] – (not used – read as 0)
[23...16] – (R/W) – DAC value channel 7
15 – (W) – load DAC channels 1 – 8
[14...8] – (not used – read as 0)
[7...0] – (R/W) – DAC value channel 8

DAC 9_10 – DAC channels 9,10 (0x60)

31 – (W) – load DAC channels 9 – 16

[30...24] – (not used – read as 0)

[23...16] – (R/W) – DAC value channel 9

15 – (W) – load DAC channels 9 – 16

[14...8] – (not used – read as 0)

[7...0] – (R/W) – DAC value channel 10

DAC 11_12 – DAC channels 11,12 (0x64)

31 – (W) – load DAC channels 9 – 16

[30...24] – (not used – read as 0)

[23...16] – (R/W) – DAC value channel 11

15 – (W) – load DAC channels 9 – 16

[14...8] – (not used – read as 0)

[7...0] – (R/W) – DAC value channel 12

DAC 13_14 – DAC channels 13,14 (0x68)

31 – (W) – load DAC channels 9 – 16

[30...24] – (not used – read as 0)

[23...16] – (R/W) – DAC value channel 13

15 – (W) – load DAC channels 9 – 16

[14...8] – (not used – read as 0)

[7...0] – (R/W) – DAC value channel 14

DAC 15_16 – DAC channels 15,16 (0x6C)

31 – (W) – load DAC channels 9 – 16

- [30...24] – (not used – read as 0)
- [23...16] – (R/W) – DAC value channel 15
- 15 – (W) – load DAC channels 9 – 16
- [14...8] – (not used – read as 0)
- [7...0] – (R/W) – DAC value channel 16

STATUS 1 – Input Buffer Status (0x70)

- 31 – (R) – data buffer (channel 1 – 8) ready for input
- 30 – (R) – data buffer (channel 1 – 8) input paused
- 29 – (R) – not used (read as ‘0’)
- 28 – (R) – data buffer (channel 1 – 8) empty
- 27 – (R) – data buffer (channel 1 – 8) full
- [26...16] – (R) – data buffer (channel 1 – 8) word count
- 15 – (R) – data buffer (channel 9 – 16) ready for input
- 14 – (R) – data buffer (channel 9 – 16) input paused
- 13 – (R) – not used (read as ‘0’)
- 12 – (R) – data buffer (channel 9 – 16) empty
- 11 – (R) – data buffer (channel 9 – 16) full
- [10...0] – (R) – data buffer (channel 9 – 16) word count

STATUS 2 – Build Buffer Status (0x74)

- [31...29] – not used (read as ‘0’)
- 28 – (R) – data buffer ‘A’ empty
- 27 – (R) – data buffer ‘A’ full

[26...16] – (R) – data buffer ‘A’ word count

[15...13] – not used (read as ‘0’)

12 – (R) – data buffer ‘B’ empty

11 – (R) – data buffer ‘B’ full

[10...0] – (R) – data buffer ‘B’ word count

STATUS 3 – Output Buffer Status (0x78)

[31...30] – not used (read as ‘0’)

29 – (R) – data buffer ‘A’ empty

28 – (R) – data buffer ‘A’ full

[27...16] – (R) – data buffer ‘A’ word count

[15...14] – not used (read as ‘0’)

13 – (R) – data buffer ‘B’ empty

12 – (R) – data buffer ‘B’ full

[11...0] – (R) – data buffer ‘B’ word count

STATUS 4 – (spare) (0x7C)

[31...0] – reserved

AUXILIARY 1 – (spare) (0x80)

[31...0] – reserved

AUXILIARY 2 – (spare) (0x84)

[31...0] – reserved

AUXILIARY 3 – (spare) (0x88)

[31...0] – reserved

AUXILIARY 4 – (spare) (0x8C)

[31...0] – reserved

RAM – Read Address (0x90)

[31...24] – not used

[23...21] – reserved (read as 0)

20 – increment address after data read

[19...0] – read address

RAM – Write Address (0x94)

[31...24] – not used

[23...21] – reserved (read as 0)

20 – increment address after data write

[19...0] – write address

RAM 1 – Data Register (0x98)

[31...0] – data word (bytes 0-3)

RAM 2 – Data Register (0x9C)

[31...0] – data word (bytes 4-7)

BERR Module Count (0xA0)

[31...0] – BERR count (driven by module to terminate data transmission)

BERR Total Count (0xA4)

[31...0] – BERR count (as detected on bus)

Auxiliary Scaler 1 (0xA8)

[31...0] – Total word count FPGA 1 (channel 1-8)

Auxiliary Scaler 2 (0xAC)

[31...0] – Total word count FPGA 2 (channel 9-16)

Auxiliary Scaler 3 (0xB0)

[31...0] – Event header word count FPGA 1 (channel 1-8)

Auxiliary Scaler 4 (0xB4)

[31...0] – Event header word count FPGA 2 (channel 9-16)

Auxiliary Scaler 5 (0xB8)

[31...0] – Event trailer word count FPGA 1 (channel 1-8)

Auxiliary Scaler 6 (0xBC)

[31...0] – Event trailer word count FPGA 2 (channel 9-16)

Module Busy Level (0xC0)

[31] – Force module busy

[30...20] – reserved

[19...0] – Busy level (eight byte words)

(External RAM word count > Busy level → module busy = 1)

Reserved (15 registers) (0xC4 – 0xFC)

The following are ADC processing FPGA registers. See *ADC FPGA Version 1* by Hai Dong for details of these registers.

ADC STATUS 0 – (0x100)

[31...16] – (R) – Status 0, FPGA 1 (channels 1 - 8)

[15...0] – (R) – Status 0, FPGA 2 (channels 9 - 16)

ADC STATUS 1 – (0x104)

[31...16] – (R) – Status 1, FPGA 1 (channels 1 - 8)

[15...0] – (R) – Status 1, FPGA 2 (channels 9 - 16)

ADC CONFIGURATION – (0x108)

[31...16] – (R/W) – Configuration, FPGA 1 (channels 1 - 8)

[15...0] – (R/W) – Configuration, FPGA 2 (channels 9 - 16)

PWT – (0x10C)

[31...16] – (R/W) – PWT, FPGA 1 (channels 1 - 8)

[15...0] – (R/W) – PWT, FPGA 2 (channels 9 - 16)

PL – (0x110)

[31...16] – (R/W) – PL, FPGA 1 (channels 1 - 8)

[15...0] – (R/W) – PL, FPGA 2 (channels 9 - 16)

NSB – (0x114)

[31...16] – (R/W) – NSB, FPGA 1 (channels 1 - 8)

[15...0] – (R/W) – NSB, FPGA 2 (channels 9 - 16)

NSA – (0x118)

[31...16] – (R/W) – NSA, FPGA 1 (channels 1 - 8)

[15...0] – (R/W) – NSA, FPGA 2 (channels 9 - 16)

Spare – (0x11C)

THRESHOLD 1_2 – (0x120)

[31...16] – (R/W) – Channel 1 threshold

[15...0] – (R/W) – Channel 2 threshold

THRESHOLD 3_4 – (0x124)

[31...16] – (R/W) – Channel 3 threshold

[15...0] – (R/W) – Channel 4 threshold

THRESHOLD 5_6 – (0x128)

[31...16] – (R/W) – Channel 5 threshold

[15...0] – (R/W) – Channel 6 threshold

THRESHOLD 7_8 – (0x12C)

[31...16] – (R/W) – Channel 7 threshold

[15...0] – (R/W) – Channel 8 threshold

THRESHOLD 9_10 – (0x130)

[31...16] – (R/W) – Channel 9 threshold

[15...0] – (R/W) – Channel 10 threshold

THRESHOLD 11_12 – (0x134)

[31...16] – (R/W) – Channel 11 threshold

[15...0] – (R/W) – Channel 12 threshold

THRESHOLD 13_14 – (0x138)

[31...16] – (R/W) – Channel 13 threshold

[15...0] – (R/W) – Channel 14 threshold

THRESHOLD 15,16 – (0x13C)

[31...16] – (R/W) – Channel 15 threshold

[15...0] – (R/W) – Channel 16 threshold

PWT Last Address – (0x140)

[31...16] – (R) – PWT last address, FPGA 1 (channels 1 - 8)

[15...0] – (R) – PWT last address, FPGA 2 (channels 9 - 16)

PWT Max Buf – (0x144)

[31...16] – (R) – PWT max buf, FPGA 1 (channels 1 - 8)

[15...0] – (R) – PWT max buf, FPGA 2 (channels 9 - 16)

The following are HITSUM FPGA registers. See *HIT SUM FPGA Version 1* by Hai Dong for details of these registers.

HITSUM STATUS – (0x200)

31...16 – not used

[15...0] – (R) – HITSUM status

HITSUM CONFIGURATION – (0x204)

31...16 – not used

[15...0] – (R/W) – HITSUM configuration

HITBITS WIDTH – (0x208)

31...16 – not used

[15...0] – (R/W) – HITBITS width channel n = adr + 1;
adr = secondary address (0x0 – 0xF)

HITS DELAY – (0x20C)

31...16 – not used

[15...0] – (R/W) – HITS delay

LIVE TRIG OUT WIDTH – (0x210)

31...16 – not used

[15...0] – (R/W) – Live trigger out width

TRIGGER HITBITS – (0x214)

31...16 – not used

[15...0] – (R/W) – Trigger hitbits

WINDOW WIDTH – (0x218)

31...16 – not used

[15...0] – (R/W) – Window width

BOOLEAN OVERLAP BITS – (0x21C)

31...16 – not used

[15...0] – (R/W) – Boolean overlap qualified bits

HIT PATTERN TABLE – (0x220)

31...1 – not used

0 – (R/W) – 1 for valid pattern; pattern = secondary address (0x0 – 0xFFFF)

HITSUM FIFO – (0x224)

31...16 – not used

[15...0] – (R) – HITSUM FIFO data

SUM THRESHOLD – (0x228)

31...16 – not used

[15...0] – (R/W) – SUM threshold